

FIG.1




FIG.2




FIG. 3




FIG.4




FIG.5




FIG.6




FIG.7

ITEM	TYPE	VALUE
RESET STATE	RESET STATE	ON/OFF
FLAG FOR DISTRIBUTION SERVICE	#1	ON/OFF
	#2	ON/OFF
	#3	ON/OFF
	#4	ON/OFF

FIG.8




FIG.9




FIG.10




FIG.11




FIG.12





FIG.13

MULTICAST GROUP ADDRESS	TRANSMISSION CHANNEL	INFORMATION CHANNEL NUMBER
239.111.102.45	#1	1
226.208.121.23	#2	2
231.131.172.10	#3	3
.
.

FIG.14



10/018005

FIG. 15




FIG.16




FIG.17




FIG.18

MULTICAST GROUP ADDRESS	TRANSMISSION CHANNEL	INFORMATION CHANNEL NUMBER	SERVICE CONTINUE CHECK SIGNAL
239.111.102.45	#1	1	1(=TRANSMISSION)
226.208.121.23	#2	2	0(=UN-TRANSMISSION)
231.131.172.10	#3	3	0(=UN-TRANSMISSION)
...
...

FIG.19




FIG.20




FIG.21




FIG.22




FIG.23






FIG.24



(a)



(b)

10/018005

FIG.25

RADIO BASE STATION NUMBER	PROGRAM TITLE	RADIO CHANNEL NUMBER	DISTRIBUTION CHECK 1	DISTRIBUTION CHECK 2
1	224.0.100.51	5	0	1
	231.21.78.93	13	0	
	228.250.141.4	8	0	
2	229.31.7.85	9	1	0
.
6	226.86.25.2	7	0	0
7	230.49.135.107	2	0	0
	239.200.3.246	4	0	

FIG.26

